



BASIC CALLS USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

INTERNAL CALLS

LIFT HANDSET OR PRESS SPEAKER PHONE

DIAL EXTENSION NUMBER OR PRESS EXTENSION BUTTON

Extension buttons are flexible keys that can be programmed to show status of an extension or to call an extension.

(Refer to programming sheet)

EXTERNAL CALLS

LIFT HANDSET OR PRESS SPEAKER PHONE

DIAL 9 OR PRESS LINE KEY

DIAL TELEPHONE NUMBER

PLACING A CALL ON HOLD

DURING A CONVERSATION

PRESS HOLD

TO RETRIEVE PRESS FLASHING LINE KEY/INTERCOM KEY OR LOOP KEY

You cannot transfer calls using the hold key.

LAST NUMBER REDIAL

LIFT HANDSET OR PRESS SPEAKER PHONE AND THEN THE REDIAL BUTTON

OR PRESS THE REDIAL BUTTON DIRECTLY

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk