



CALL BACK USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

CALL BACK

DIAL EXTENSION NUMBER OR PRESS EXTENSION BUTTON (BUSY TONE)

DIAL 6

The system will automatically call you back when the extension is free.

Extensions that have set call forward busy or busy/no answer to voicemail or to another extension this feature will not work.

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk