



CALL PICK UP USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

GROUP CALL PICK UP

DIAL *40 PLUS GROUP NUMBER (01-32)
SPEAK AFTER TONE

DIRECT CALL PICK UP

DIAL *41 + EXTENSION NUMBER
SPEAK AFTER TONE

If you have a button programmed for that particular extension simply press the button, which will be flashing red. Group pick up can be programmed as a button on your phone (Refer to programming sheet).

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk