



CONFERENCE CALLS 3-8 PARTIES USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

INTERNAL/EXTERNAL

DURING A CALL PRESS CONFERENCE BUTTON
DIAL INTERNAL EXTENSION NUMBER OR DIAL (9) + EXTERNAL NUMBER
WAIT FOR ANSWER
PRESS CONFERENCE

External conference calls require system programming.
Panasonic DT-321 handsets require a pre-programmed conference call button.
To leave a 3 party conference call you must press TRANSFER first before hanging up.
To leave a multiple conference call you must press CONF first before hanging up.

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk