



PAGING USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

MAKING A PAGE CALL

DIAL *33 PLUS GROUP NUMBER (01 – 32)
SPEAK AFTER TONE

In default all group numbers are located in paging group 01.

ANSWERING A PAGE CALL FROM ANY EXTENSION

DIAL *43
SPEAK AFTER TONE

TO ALLOW/DENY A PAGE CALL THROUGH YOUR HANDSET

DIAL *7210 (TO ALLOW PAGE)
DIAL *7211 (TO DENY PAGE)

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk