



SETTING HANDSET RING TONES USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

SETTING INTERNAL RING TONES

HANDSET MUST REMAIN ON THE REST
PRESS PROG
PRESS YOUR INTERCOM BUTTON TWICE
CHOOSE YOUR RING TONE TYPE
PRESS ENTER OR AUTODIAL/STORE

SETTING EXTERNAL RING TONES

HANDSET MUST REMAIN ON THE REST
PRESS PROG
PRESS YOUR LINE KEY/GROUP KEY OR LOOP KEY BUTTON TWICE
CHOOSE YOUR RING TONE TYPE
PRESS ENTER OR AUTODIAL/STORE

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk