



## **USER HANDSET KEY PROGRAMMING USER GUIDE**

### **FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS**

#### **PROGRAMMING REQUIRES THE HANDSET TO REMAIN ON THE REST**

#### **PROGRAMMING EXTENSION KEYS**

1. PRESS PROG OR PROGRAM
2. PRESS THE DESIRED BUTTON YOU WISH TO PROGRAM
3. DIAL 1 PLUS THE EXTENSION NUMBER
4. PRESS ENTER OR AUTO/DIAL STORE BUTTON

On storing your keys in step 4 this will take you back to step 2 were you can program remaining keys.

#### **PROGRAMMING EXTERNAL TELEPHONE NUMBER KEYS**

1. PRESS PROG OR PROGRAM
2. PRESS THE DESIRED BUTTON YOU WISH TO PROGRAM
3. DIAL 2 THEN (9) + TELEPHONE NUMBER
4. PRESS ENTER OR AUTO/DIAL STORE BUTTON

On storing your keys in step 4 this will take you back to step 2 were you can program remaining keys.

#### **PROGRAMMING PICK UP KEY**

1. PRESS PROG OR PROGRAM
2. PRESS THE DESIRED BUTTON YOU WISH TO PROGRAM
3. DIAL 2 THEN \*4001 FOR PICK UP GROUP 1 or DIAL \*40 (02-32) FOR REMAINING GROUPS

#### **PROGRAMMING PAGING KEY**

1. PRESS PROG OR PROGRAM
2. PRESS THE DESIRED BUTTON YOU WISH TO PROGRAM
3. DIAL 2 THEN \*3301 FOR PAGING GROUP 1 or DIAL \*33 (02-32) FOR REMAINING GROUPS

# Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF  
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk



#### **PROGRAMMING PARK HOLD KEY**

1. PRESS PROG OR PROGRAM
2. PRESS THE DESIRED BUTTON YOU WISH TO PROGRAM
3. DIAL 52
4. PRESS ENTER/ AUTODIAL STORE
5. DIAL PARK NUMBER (00-99)
6. PRESS ENTER/AUTODIAL STORE

#### **PROGRAMMING HEADSET**

1. PRESS PROG OR PROGRAM
2. DIAL 61
3. PRESS ENTER OR AUTO/DIAL STORE BUTTON
4. PRESS UP OR DOWN ON JOG DIAL WHEEL
5. PRESS ENTER OR AUTO/DIAL STORE BUTTON

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF  
Telephone: 01264 336644 - Fax: 01264 332083 - email: [info@sbclimited.co.uk](mailto:info@sbclimited.co.uk)